



Note 1: Only to be used for passive venting of unconditioned attic space.

Note 2: Opening in deck must not exceed vent size.

Note 3: Locate raised marks on vent base. Aligned to raised marks, measure 2 inches up vent cap and predrill a 3/16-inch hole through vent cap on opposing sides (Total of 2). Install 4-Inch fasteners through predrilled holes of vent cap and into vent base.

Note 4: All field welds shall be a minimum of 1-1/2 inches wide.

Note 5: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 02/02/2017	VENT DETAIL FOR UNCONDITIONED ATTIC SPACE
PREVIOUS: 01/01/2012	PLENUM VENT
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF