



Note 1: Place the appropriately sized galvanized base over the pipe in the roof deck, per applicable codes.

Note 2: Fasten the base to the deck using four approved fasteners, 1-1/2 in. (38 mm) from each outside corner and penetrating at least 1 in. (25 mm) into the deck.

Note 3: Apply caulk between the base and flashing within 1 in. (25 mm) of the top of the flashing.

Note 4: Place the hood assembly over the flashing and base. Secure with a minimum of two approved fasteners directly through the caulk line. **The screws must penetrate the base by a minimum of 1/2 in. (13 mm).**

Note 5: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.

Note 6: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: 00/00/0000	PVC VENT DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/24/2026	TYPE B GAS VENT ASSEMBLY
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF