



Note 1: Place the appropriately sized T-Top over the vent hole in the roof deck.

Note 2: Fasten the base to the deck using four approved fasteners, 1-1/2 in. (38 mm) from each outside corner and penetrating at least 1 in. (25 mm) into the deck.

Note 3: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.

Note 4: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: 00/00/0000	PVC VENT DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/24/2026	T-TOP VENT
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF