

SMART-LADDER REST™

DESCRIPTION:

The Smart-Ladder Rest™ is a permanent fixture for use in stabilizing extension ladders for safe roof access.





Available separately or with gutter extensions, which accommodate up to 8-inch (203 mm) wide gutters, the Smart-Ladder Rest fulfills requirements for OSHA compliance and prevents unsafe ladder instability.

Combining the Duro-Last® PVC Roofing System with the Smart-Ladder Rest allows for sustained waterproofing in conjunction with enhanced ladder safety.

ORDERING:

The Smart-Ladder Rest is made of sand-blasted stainless steel, comes with four Duro-Last PVC, or Duro-Last EV, Butterfly Corners, and is available in the following options:

- Smart-Ladder Rest only, with 4 Butterfly Corners
- Smart-Ladder Rest with Gutter Extension and 4 Butterfly Corners (includes extension anchor and bolts with zinc lock nuts for attachment)

| SMART-LADDER REST ORDERING | | | |
|----------------------------|---|------------------------|---------------------------------------|
| BUTTERFLY CORNER COLORS | | SMART-LADDER REST ONLY | SMART-LADDER REST W/ GUTTER EXTENSION |
| White/ White EV |  | 1219W/ 1219EV | 2219W/ 2219EV |
| Tan |  | 1219B | 2219B |
| Gray |  | 1219G | 2219G |
| Dark Gray |  | 1219DG | 2219DG |



INSTALLATION

- Wood blocking must be installed below support if insulation is used in the roofing system.
 - Deck membrane must be installed prior to installing the Smart-Ladder Rest.
 - If installing above a gutter, deck membrane must be back-sealed with an approved sealant.
 - Add edge details after Smart-Ladder Rest installation.
1. Fasten the Smart-Ladder Rest or Gutter Extension to the deck with approved fasteners.
 - Must fasten all 6 holes on each side.
 2. Position and weld Butterfly Corners as shown in Details 4210 and 4211.
 - Trim as necessary.
 3. Apply approved sealant between the Smart-Ladder Rest and the Butterfly Corners.
 - Extend sealant approximately 1/4 inch (6 mm) below the top edge of the Butterfly Corners.
 4. Install a stainless steel band approximately 1/4 inch (6 mm) from the top of the Butterfly Corners.
 5. Apply approved caulk along top edge of the banded Butterfly Corners.

