



INSTRUCTIONS

1. Drill 1/4 in. diameter holes in the bottom of the flutes on the existing-roof side of the tie-in only when they will be covered with new roofing material.
2. Apply approved sealant to underside of material and fasten with Termination Bar before the urethane foam is installed.
3. Fill between the flutes with urethane foam level with the top flutes.

Note 1: This detail is **not** approved for final termination. See Details T1080, T1100 or T8040 for the appropriate completion of this detail.

Note 2: This detail is **not** approved on metal retrofit applications.

Note 3: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: N/A	TPO GENERAL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/11/2025	CROSS-FLUTE METAL DECK TERMINATION
SCALE: NONE	RE-ROOF