



Note 1: Position each successive roll to overlap the fastened edge of the installed membrane by 6 in. (152 mm). Fasten with approved plates and fasteners in accordance with the Duro-TECH TPO Mechanically Fastened Roofing System Specification.

Note 2: On mechanically fastened systems, the fastening plates must be installed 1/2 - 1 in. (13 - 25 mm) away from the membrane edge.

Note 3: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.

REVISED:	N/A	TPO GENERAL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS:	02/14/2025	MEMBRANE PLATE POSITIONING
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF