



Note 1: This detail may also be used on parapet walls.

Note 2: If used in a gutter, back-seal membrane with an approved sealant and fasten 6 in. (152 mm) on center with approved fasteners.

Note 3: TPO-Coated Metal Drip Edge with a 4 in. (102 mm) face or greater requires a continuous cleat fastened 6 in. (152 mm) on center. Use roofing nails that penetrate substrate by a minimum of 1-1/2 in. (40 mm).

Note 4: Each section must overlap by 1-1/2 in. (40 mm).

Note 5: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.

Note 6: Refer to General Requirements for wood nailer requirements.

Note 7: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: N/A	TPO EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 05/15/2025	TPO-COATED METAL DRIP EDGE
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF