



Note 1: This detail may also be used on parapet walls.

Note 2: Refer to appropriate Detail for installation instructions of edge detail.

Note 3: Install adjacent sections of Metal Edge Extender over expansion tabs and allow for 1/8 in. (3 mm) gap between overlapping sections. Refer to Detail T3500.

Note 4: If Metal Edge Extender is 4 in. (102 mm) or larger, a continuous cleat is required.

| | |
|----------------------|---|
| REVISED: N/A | TPO METAL EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS |
| PREVIOUS: 02/17/2025 | METAL EDGE EXTENDER |
| SCALE: NONE | NEW CONSTRUCTION OR RE-ROOF |