



- Note 1: Membrane must be fastened around the perimeter of the drain with the same fastening pattern as the field membrane, no less than one fastener per drain.
- Note 2: Openings in the CDRs must face in opposite directions. Sealant must be behind the membrane at the CDRs' location.
- Note 3: Drain guard attachment tabs are secured to the roof membrane by heat welding. Do not mechanically fasten.
- Note 4: Drain boots are made to fit specific drain sizes. Never install a drain boot into a drain of a different size.
- Note 5: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.
- Note 6: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: N/A	TPO DRAINAGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/17/2025	ROOF DRAIN WITH DRAIN GUARD
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF