



Note 1: Lead flashings must be removed prior to installing Stack Flashings.

Note 2: Membrane must be fastened around the perimeter of the drain with the same fastening pattern as the field membrane, no less than one fastener per drain.

Note 3: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.

Note 4: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: N/A	TPO DRAINAGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/17/2025	OVERFLOW DRAIN
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF