



Note 1: For membrane installation, refer to detail T3020.

Note 2: All joints, splices, corners, and end caps are to be riveted into position. On splice plates, a minimum of two rivets and two fasteners are to be installed as shown above.

Note 3: All joints, splices, corners, and end caps must have approved sealant applied to them to ensure a water-tight application. Apply a bead of approved sealant to the splice plate on both sides of joint.

Note 4: For every 40 – 50 ft (12 – 15 m) of gutter, install one expansion joint. Refer to Detail T2095.

Note 5: Gutter straps spaced 24 – 30 in. (609 – 762 mm) on center.

Note 6: Drainage slopes and drain sizes are to be determined by local building code requirements and are contractor's responsibility to follow.

Note 7: Refer to General Requirements for wood nailer requirements.

Note 8: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: N/A	TPO DRAINAGE DETAIL
PREVIOUS: 02/17/2025	GUTTER ATTACHMENT - X-SERIES
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF