



INSTRUCTIONS

1. Precut a 14 x 10 in. (356 x 254 mm) opening in upper third of parapet a minimum of 8 in. (203 mm) from finished roof surface.
2. Install parapet flashing according to Details TRG6012 and TRG6013.
3. Cut parapet flashing to size of precut opening and backseal with approved sealant (see side profile).
4. Install TPO Parapet Vent over opening and fasten metal flanges with pre-punched holes (minimum of 2 per side).
5. Weld entire perimeter of 6 in. (152 mm) skirt with a minimum of a 1-1/2 in. (40 mm) field weld to the parapet flashing.

REVISED: N/A	TPO VENT DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 05/23/2025	PARAPET VENT
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF