



## INSTRUCTIONS

1. Install coping cleat per Detail T6050 or T6052.
2. Install splice plate centered on coping joint. Install approved sealant along both long top edges of splice plate.
3. Install coping cap over top of splice plate. Leave a 1/4-in. (6-mm) gap between sections of coping to allow for expansion and contraction.

**Note:** All joining surfaces such as joints, splices, corners, and end caps must have an approved sealant applied to them.

REVISED: N/A	TPO PARAPET DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 05/19/2025	COPING CAP SPLICE PLATE INSTALLATION
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF