



Note 1: Deck membrane must be fastened around the perimeter of the roof access hatch as per the respective zone the roof access hatch is located within (field, perimeter, corner).

Note 2: Flashing membrane must loop over the foam backer rod. Foam backer rod must be of sufficient size to compress when installed.

Note 3: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.

Note 4: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED:	N/A	TPO ROOF PENETRATION DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS:	07/11/2025	ROOF ACCESS HATCH - OPTION 1
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF