



Note 1: Install parapet flashing as per Details TRG6012 or TRG6013.

Note 2: Splice cleats are installed 24 in. (610 mm) on center using 4 approved fasteners. Splice cleats must be located at each joint.

Note 3: When more than one piece of Arched Coping is used, always overlap each piece from bottom to top (shingle lapping), ending with the final piece centered at the top of the arch.

Note 4: Coping that is 16 to 24 in. (406 to 610 mm) wide will require a row of hex head screws and neoprene washers installed along the center at 18 in. (457 mm) on center.

Note 5: Coping that is 25 in. (635 mm) or wider will require 2 rows of hex head screws and neoprene washers installed 6 in. (152 mm) from each edge at 18 in. (457 mm) on center.

Note 6: Edges are pre-notched to allow for an overlapping joint. Apply an approved sealant at all joints as shown above.

Note 7: Hex head screws must penetrate into nailer by a minimum of 1-1/2 in. (40 mm).

Note 8: Refer to General Requirements for wood nailer requirements.

REVISED: N/A	TPO EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 05/19/2025	ARCHED COPING WITH SPLICE CLEAT
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF