



Note 1: This detail is required when there are gaps between deck and parapet.

Note 2: Tabs that are parallel to the expansion joint must be mechanically fastened with the same fastening pattern used on the membrane in the field area.

Note 3: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.

Note 4: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: N/A	TPO PARAPET DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 06/03/2025	MOISTURE BARRIER AT PARAPET TRANSITION
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF