



Note 1: Membrane parallel to the expansion joint must be mechanically fastened with the same fastening pattern used on the membrane in the field area.

Note 2: Leave the membrane covering the expansion joint loose enough to allow for movement of the building on either side of the joint.

Note 3: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.

Note 4: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: N/A	TPO GENERAL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/12/2025	CURB-STYLE EXPANSION JOINT
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF