



- Note 1: Membrane must be fastened around the perimeter of the drain with the same fastening pattern as the field membrane, no less than 1 fastener per drain.
- Note 2: Openings in the CDRs must face in opposite directions. Sealant must be behind the membrane at the CDRs' location.
- Note 3: Drain guard attachment tabs are secured to the roof membrane by heat welding. Do not mechanically fasten.
- Note 4: Drain boots are made to fit specific drain sizes. Never install a drain boot into a drain of a different size.
- Note 5: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.
- Note 6: Refer to specifications for vapor barrier, insulation, and cover board requirements.

| | | |
|-----------|------------|----------------------------------------------------|
| REVISED: | N/A | TPO DRAINAGE DETAIL FOR ADHERED NON FLEECE SYSTEMS |
| PREVIOUS: | 09/26/2025 | ROOF DRAIN WITH DRAIN GUARD |
| SCALE: | NONE | NEW CONSTRUCTION OR RE-ROOF |