



Note 1: Membrane must be fastened around the perimeter of the drain with the same fastening pattern as the field membrane, no less than one fastener per drain.

Note 2: The openings in the composite drain rings (CDR) must face in opposite directions. Sealant and CDRs are to match locations.

Note 3: The top of the CDRs must be a minimum of 2 inches from the top of the overflow drain.

Note 4: All field welds shall be a minimum of 1-1/2 inches wide.

Note 5: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED:	07/28/17	DRAINAGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS:	07/28/17	OVERFLOW DRAIN
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF