



- Note 1: Membrane must be fastened around the perimeter of the drain with the same fastening pattern as the field membrane, no less than one fastener per drain.
- Note 2: The openings in the composite drain rings (CDR) must face in opposite directions. Sealant and CDRs are to match locations.
- Note 3: The top of the CDRs must be a minimum of 2 inches from the top of the overflow drain.
- Note 4: All field welds shall be a minimum of 1-1/2 inches wide.
- Note 5: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 01/31/2017	DRAINAGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 01/01/2009	OVERFLOW DRAIN
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF