



Note 1: Overlapping 6 inches and cutting back fastening tabs allows adequate space for fastening and field seaming. When cutting back the fastening tab, be careful not to cut the top layer of membrane.

Note 2: Extra precautions must be taken to ensure T-laps are welded properly.

Note 3: Membrane is shown as transparent in order to display the fastening plates and seams.

REVISED:	12/8/17	GENERAL DETAIL FOR MECHAINCALLY FASTENED SYSTEMS
PREVIOUS:	07/17/17	CUSTOM FABRICATED DECK SHEET SEAMING
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF