



Note 1: Overlapping 6 inches and cutting back fastening tabs allows adequate space for fastening and field seaming. When cutting back the fastening tab, be careful not to cut the top layer of membrane.

Note 2: Extra precautions must be taken to ensure T-laps are welded properly.

REVISED: 01/30/2017	GENERAL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 01/01/2009	CUSTOM-FABRICATED DECK SHEET SEAMING
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF