



INSTRUCTIONS

1. Drill 1/4-inch diameter holes in the bottom of the flutes on the existing-roof side of the tie-in only when they will be covered with new roofing material.
2. Apply approved sealant to underside of material and fasten with Duro-Last Termination Bar before the urethane foam is installed.
3. Fill between the flutes with urethane foam level with the top flutes.

Note 1: This detail is not approved for final termination. See Detail Drawings 1080, 1100 or 8040 for the appropriate completion of this detail.

Note 2: This detail is not approved on metal retrofit applications.

Note 3: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 01/30/2017	GENERAL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 01/01/2009	CROSS-FLUTE METAL DECK TERMINATION
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF