



Note 1: Tabs that are parallel to the expansion joint must be mechanically fastened with the same fastening pattern used on the membrane in the field area.

Note 2: Leave the membrane covering the expansion joint loose enough to allow for movement of the building on either side of the joint.

Note 3: All field welds shall be a minimum of 1-1/2 inches wide.

Note 4: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED:	12/1/17	GENERAL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS:	07/18/17	CURB-STYLE EXPANSION JOINT
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF