



**Note 1: The use of this detail is not allowed on fully adhered installations.**

See detail AS3110 in the adhered systems section.

**Note 2:** The use of this detail is not to exceed a 2-inch per 12-inch slope.

**Note 3:** A wood nailer is required if one or more inches of insulation is used. Top of wood nailer extends at least 1/2-inch beyond the horizontal edge of the snap-on base.

**Note 4:** The fasteners used to attach the base to wood nailers, and the membrane to the face of the nailers, must be spaced no greater than 6-inches on-center when attaching the base within 10-feet (min.) of the outside corners of the building.

**Note 5:** Allow for 1/8-inch expansion gap between 10-foot lengths of snap-on base. Overlap the snap-on covers by 2-inches between 10-foot lengths.

**Note 6:** When installing this detail with a 6-inch or greater vertical surface, additional mechanical attachment is required on the snap on base.

REVISED:	12/5/17	EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS:	07/20/17	2-PIECE COMPRESSION EDGE
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF