



Note 1: **The use of this detail is not allowed on fully adhered installations.**
See detail AS3115 in the adhered systems section.

Note 2: The use of this detail is not to exceed a 2-inch per 12-inch slope.

Note 3: A wood nailer is required if one or more inches of insulation is used. Top of wood nailer extends at least 1/2-inch beyond the horizontal edge of the snap-on base.

Note 4: The fasteners used to attach the base to wood nailers, and the membrane to the face of the nailers, must be spaced no greater than 6-inches on-center when attaching the base within 10-feet (min.) of the outside corners of the building.

Note 5: Allow for 1/8-inch expansion gap between 10-foot lengths of snap-on base. Overlap the snap-on covers by 2-inches between 10-foot lengths.

Note 6: When installing this detail with a 6-inch or greater vertical surface, additional mechanical attachment is required on the snap on base.

| | | |
|-----------|----------|--|
| REVISED: | 12/5/17 | EDGE DETAILS FOR MECHANICALLY FASTENED SYSTEMS |
| PREVIOUS: | 07/20/17 | 2-PIECE COMPRESSION LG. |
| SCALE: | NONE | NEW CONSTRUCTION OR RE-ROOF |