



Note 1: This detail may also be used on parapet walls.

Note 2: If used in a gutter, back-seal membrane with an approved Duro-Last sealant and fasten 6 inches on center with approved Duro-Last fasteners. Refer to Detail Drawing 3050.

Note 3: Vinyl-Coated Metal Drip Edge with a 4-inch face or greater requires a continuous cleat fastened 6 inches on center. Use roofing nails that penetrate substrate by a minimum of 1-1/2 inches.

Note 4: Each section must overlap by 1-1/2 inches.

Note 5: All field welds shall be a minimum of 1-1/2 inches wide.

Note 6: Wood nailers must withstand a minimum force of 180 pounds per lineal foot (per building code). Any pull values greater than 270 pounds will allow for a fastener spacing of 18 inches on center. Pull values less than 270 pounds will require additional fasteners. **The installing contractor is responsible for meeting building codes.**

Note 7: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 09/07/2017	EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 01/01/2009	VINYL-COATED METAL DRIP EDGE
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF