



Note 1: This detail may also be used on parapet walls.

Note 2: Refer to appropriate Detail Drawing for installation instructions of edge detail.

Note 3: All fasteners must penetrate substrate by a minimum of 1-1/2 inches.

Note 4: Install adjacent sections of Metal Edge Extender over expansion tabs and allow for 1/8-inch gap between overlapping sections. Refer to Detail Drawing 3500.

Note 5: If Edge Extender is 4 inches or larger, a continuous cleat is required.

REVISED:	12/18/17	METAL EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS:	07/21/17	METAL EDGE EXTENDER
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF