



- Note 1: This detail may also be used on parapet walls.
- Note 2: Refer to appropriate Detail Drawing for installation instructions of edge detail.
- Note 3: All fasteners must penetrate substrate by a minimum of 1-1/2 inches.
- Note 4: Install adjacent sections of Metal Edge Extender over expansion tabs and allow for 1/8-inch gap between overlapping sections. Refer to Detail Drawing 3500.
- Note 5: If Edge Extender is 4 inches or larger, a continuous cleat is required.

REVISED: 04/14/2017	METAL EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 01/01/2009	METAL EDGE EXTENDER
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF