



Note 1: Lead flashings must be removed prior to installing Duro-Last Stack Flashings.

Note 2: Deck membrane shall be fastened around the perimeter of the Duro-Last Stack Flashing as per the respective zone the Duro-Last Stack Flashing is located within (field, perimeter, corner), no less than one fastener per flashing.

Note 3: All field welds shall be a minimum of 1-1/2 inches wide.

Note 4: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED:	11/30/17	ROOF PENETRATION DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS:	08/02/17	ROUND PENETRATION
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF