



INSTRUCTIONS

1. Fasten deck membrane at peak opening to secure in place.
2. Install 16-gauge support chair brackets 5 feet on center along length of ridge vent with approved Duro-Last fasteners.
3. Install splice plates by locating center of vented ridge cap joints. Apply a bead of approved Duro-Last caulk on both sides of splice plates as shown above. Do not fasten splice plates.
4. Rivet end caps to vented ridge caps as shown above. Make sure to do this step before installing vented ridge caps to deck. Apply approved Duro-Last caulk to inside of vented ridge cap and end cap at each joint and rivet.
5. Install vented ridge caps over splice plates allowing for a 1/4-inch gap between each vented ridge cap for expansion and contraction. Cut final piece as needed for length of ridge vent. Fasten hidden flanges at 6 inches on center with approved Duro-Last fasteners. Weld membrane skirt to deck membrane with a 1 1/2-inch weld, minimum.
6. Apply approved Duro-Last caulk to bottom of each installed end cap where it meets the deck membrane as shown above.

REVISED:	11/28/17	VENT DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS:	07/25/17	VENTED RIDGE CAP INSTALLATION
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF