



Note 1: Install Duro-Last Parapet Flashing as per Detail Drawing 6010.

Note 2: Splice cleats are required when face size is 4 inches or greater. Splice cleats are installed 24 inches on center using 4 approved Duro-Last fasteners. Splice cleats must be located at each joint.

Note 3: Approved Duro-Last fasteners are spaced no greater than 6 inches on center.

Note 4: When more than 1 piece of Arched Drip Edge is used, install the first piece centered at the top of the arch.

Note 5: This detail requires the 6-inch wide membrane stripping to be field welded.

Note 6: Edges are pre-notched to allow for an overlapping joint. Apply an approved Duro-Last sealant at all joints as shown above.

Note 7: Wood nailers must withstand a minimum force of 180 pounds per lineal foot (per building code). Any pull values greater than 270 pounds will allow for a fastener spacing of 18 inches on center. Pull values less than 270 pounds will require additional fasteners. **The installing contractor is responsible for meeting building codes.**

REVISED: 04/29/2017

EDGE DETAIL FOR MECHANICALLY FASTENED SYSTEMS

PREVIOUS: 04/01/2010

ARCHED DRIP EDGE WITH SPLICE CLEAT

SCALE: NONE

NEW CONSTRUCTION OR RE-ROOF