



- Note 1: This detail is required when there are gaps between deck and parapet wall.
- Note 2: Tabs that are parallel to the expansion joint must be mechanically fastened with the same fastening pattern used on the membrane in the field area.
- Note 3: All field welds shall be a minimum of 1-1/2 inches wide.
- Note 4: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 08/29/22	PARAPET WALL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 02/08/17	MOISTURE BARRIER AT WALL TRANSITION
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF