



Note 1: This detail is required when there are gaps between deck and parapet wall.

Note 2: Tabs that are parallel to the expansion joint must be mechanically fastened with the same fastening pattern used on the membrane in the field area.

Note 3: All field welds shall be a minimum of 1-1/2 inches wide.

Note 4: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 03/10/2017	PARAPET WALL DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 01/31/2017	MOISTURE BARRIER AT WALL TRANSITION
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF