



Note 1: This detail is not allowed when roof slope exceeds 2 inches vertically per 12 inches horizontally.

Note 2: A wood nailer is required if 1 or more inches of insulation is used. top of wood nailer is to be flush with top of insulation. Wood nailer must extend at least 1/2 inch beyond the horizontal edge of the snap-on base.

Note 3: The fasteners used to attach the snap-on base and the membrane to the nailer, or into an approved structural surface, must be spaced no greater than 6 inches on center. When installing within 10 feet of an outside corner, the fasteners must be spaced no greater than 3 inches on center.

Note 4: For approved adhesives, refer to Section 2 of the Adhered Duro-Fleece roofing system specification.

Note 5: Allow for 1/8 inch expansion gap between 10-foot lengths of snap-on base. Overlap the snap-on covers by 2 inches between 10-foot lengths.

Note 6: When installing this detail with a 6 to 13-inch wide metal cover, fasteners must be located within 2 inches of the kick-out.

Note 7: For substrate options, see Section 2 of the Adhered Duro-Fleece Roofing System Specification.

REVISED:	12/15/17	ADHERED DURO-FLEECE MEMBRANE
PREVIOUS:	08/07/17	2-PIECE COMPRESSION EDGE
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF