



Note 1: This detail is not allowed when roof slope exceeds 2 inches vertically per 12 inches horizontally.

Note 2: A wood nailer is required if one or more inches of insulation is used. Top of wood nailer is to be flush with top of insulation.

Note 3: Wood nailer must extend at least 1/2 inch beyond the horizontal edge of the snap-on base.

Note 4: The fasteners used to attach the snap-on base and the membrane to the nailers, or approved structural surface, must be spaced no greater than 6-inches on-center when attaching the base within 10-feet (min.) of the outside corner, the fasteners must be spaced no greater than 3 inches on center.

Note 5: Allow for 1/8-inch expansion gap between 10-foot lengths of snap-on base. Overlap the snap-on covers by 2-inches between 10-foot lengths.

Note 6: When installing this detail with a 6-inch or greater vertical surface, fasteners must be located within 2 inches of the kick-out.

REVISED:	12/15/17	EDGE DETAIL FOR ADHERED SYSTEMS
PREVIOUS:	07/24/17	2-PIECE COMPRESSION EDGE
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF