



Note 1: Primer is not required when roof system is mechanically fastened or when substrate is a metal deck. All other substrates require primer.

Note 2: Stagger end laps a minimum of 3 feet.

Note 3: For metal decks, install 24 gauge metal plate (6 x 42 inches) at end of each roll to support end-laps. Do not fasten.

Note 4: Position rolls to create 6-inch overlaps at ends and 3-inch overlaps at sides.

Note 5: Mastic is not required unless Duro-Last® Vapor Barrier will be used as a temporary roof. When required, seal 6 inches out from all T-Lap edges as shown above.

Note 6: If mastic is used, do not allow it to contact Duro-Last membrane. A proper slip sheet or insulation must be used to separate both products.

REVISED:	12/5/17	GENERAL DETAIL FOR VAPOR BARRIER
PREVIOUS:	08/07/17	OVERLAPS AND T-LAPS
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF