



Note 1: Primer is not required when roof system is mechanically fastened or when substrate is a steel deck. All other situations require primer.

Note 2: Fill all gaps with urethane foam prior to installation of roofing membrane. Shave excess foam level to top of insulation/cover board.

Note 3: Mastic is not required unless Duro-Last® Vapor Barrier will be used as a temporary roof. When required, seal 6 inches out from all T-Lap edges as shown above.

Note 4: If mastic is used, do not allow it to contact Duro-Last membrane. A proper slip sheet or insulation must be used to separate both products.

Note 5: Refer to specifications for vapor barrier, insulation and cover board requirements.

Note 6: Use of this detail does not meet requirements for air barrier assemblies as defined under section C402.1.2.2 ASSEMBLIES of the International Energy Conservation Code.

REVISED: 08/10/2017

GENERAL DETAIL FOR VAPOR BARRIER

PREVIOUS: 04/01/2014

ROUND PENETRATION - OPTION 1

SCALE: NONE

NEW CONSTRUCTION OR RE-ROOF