



Note 1: Fill all gaps with spray foam prior to installation of vapor barrier.  
Shave excess foam level to deck.

Note 2: Prime surfaces as required by Vapor Barrier Product Data Sheet.

Note 3: If vapor barrier will be used as a temporary roof, utilize Duro-Guard® mastic to seal edges of T-Laps and overlaps as shown above.  
Edges must be sealed a minimum of 6 inches out from each T-Lap.

Note 4: If duro-Guard mastic is used, do not allow contact to the Duro-Last membrane.  
A proper slip sheet or insulation must be used to separate both products.

Note 5: Meets requirements for air barrier assemblies as defined under section C402.1.2.2 ASSEMBLIES of the International Energy Conservation Code.

REVISED:	12/7/17	ROUND PENETRATION - OPTION 2
PREVIOUS:	08/07/17	DURO-GUARD VAPOR BARRIER
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF