



Note 1: If the mechanical units are of a size that they will crush the insulation, then the insulation below the sleeper must be replaced by wood blocking.

Note 2: Attach mechanical unit to sleeper per equipment manufacturer's instructions.

Note 3: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.

Note 4: Refer to specifications for vapor barrier, insulation, and cover board requirements.

REVISED: N/A	TPO ROOF PENETRATION DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 05/05/2026	WOOD SLEEPER
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF