



INSTRUCTIONS

1. Membrane must be installed on parapet wall prior to applying Conduit/Escutcheon Washer. Ensure that Conduit/Escutcheon Washer covers membrane by at least 1 in. (25 mm).
2. Apply approved caulk on entire back surface of Conduit/Escutcheon Washer and around conduit.
3. Align splice on Conduit/Escutcheon Washer at bottom side of conduit. Attach Conduit/Escutcheon Washer with 3 approved fasteners through predrilled holes.
4. Apply approved caulk around conduit, around outside of Conduit/Escutcheon washer, and over the splice.

Note: This detail is only acceptable on vertical surfaces that are 8 in. (203 mm) or higher above the roof deck.

REVISED: N/A	TPO ROOF PENETRATION DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 05/05/2026	CONDUIT/ESCUTCHEON WASHER
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF