



- Note 1: Membrane must be fastened around the perimeter of the drain as per respective zone the drain is located within (field, perimeter, corner). No less than one fastener per drain.
- Note 2: Openings in the CDRs must face in opposite directions. Sealant must be behind the membrane at the CDRs' location.
- Note 3: Duro-Last Drain Guard attachment tabs are secured to the roof membrane by heat welding. Do not mechanically fasten.
- Note 4: Duro-Last Drain Boots are made to fit specific drain sizes. Never install a Duro-Last Drain Boot into a drain of a different size.
- Note 5: All field welds shall be a minimum of 1-1/2 inches wide.
- Note 6: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 10/14/22	DRAINAGE DETAIL FOR ADHERED NON-FLEECE SYSTEMS
PREVIOUS: N/A	ROOF DRAIN WITH DRAIN GUARD
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF