



- Note 1: Precaution must be taken to ensure that all wall-to-deck transitions are sealed.
- Note 2: Termination Bar support bracket shall be used to support the membrane until the Duro-Last sealant cures. Do not fasten the support bracket.
- Note 3: All field welds shall be a minimum of 1-1/2 inches wide.
- Note 4: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: 09/28/22	DRAINAGE DETAIL FOR ADHERED NON-FLEECE SYSTEMS
PREVIOUS: N/A	CLOSED-END MEMBRANE SCUPPER
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF