



**INSTRUCTIONS:**

1. Drill 1/4-inch diameter holes in the bottom of the flutes on the existing-roof side of the tie-in only when they will be covered with new roofing material.
2. Apply approved sealant to underside of material and fasten with Duro-Last Termination Bar before the urethane foam is installed.
3. Fill between the flutes with urethane foam level with the top flutes.

Note 1: This detail is not approved for final termination. See Detail Drawings AS1080, AS1100 or AS8040 for the appropriate completion of this detail.

Note 2: This detail is not approved on metal retrofit applications.

Note 3: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED: N/A	GENERAL DETAIL FOR ADHERED NON-FLEECE SYSTEMS
PREVIOUS: 09/06/2023	CROSS-FLUTE METAL DECK TERMINATION
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF