



- Note 1: This detail may also be used on parapet walls.
- Note 2: Refer to appropriate Detail for installation instructions of edge detail.
- Note 3: All fasteners must penetrate substrate by a minimum of 1-1/2 in. (40 mm).
- Note 4: Install adjacent sections of Metal Edge Extender over expansion tabs and allow for 1/8 in. (3 mm) gap between overlapping sections. Refer to Detail TAS3510.
- Note 5: If Metal Edge Extender is 4 in. (102 mm) or larger, a continuous cleat is required.

REVISED: N/A	TPO METAL EDGE DETAIL FOR ADHERED NON FLEECE SYSTEMS
PREVIOUS: 09/26/2025	METAL EDGE EXTENDER
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF