



Note 1: Detail Drawing AS9060C may be used in lieu of Detail Drawings AS9060A and AS9060B, but not within special wind regions or on parapet walls, when a peel stop is required. Refer to Detail Drawing AS9060 for peel stop requirements.

Note 2: A wood nailer is required if one or more inches of insulation is used. Top of the wood nailer is to be flush with the top of the insulation.

Note 3: Allow for 1/8 inch expansion gap between 10 foot lengths of snap-on base. Overlap the snap-on covers by 2 inches between 10 foot lengths.

Note 4: When installing this detail with a 6 inch or greater vertical surface, fasteners must be located within 2 inches of the kick-out.

Note 5: Wood nailers must withstand a minimum force of 180 pounds per lineal foot (per building code). Any pull values greater than 270 pounds will allow for a fastener spacing of 18 inches on center. Pull values less than 270 pounds will require additional fasteners. **The installing contractor is responsible for meeting building codes.**

Note 6: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED:	N/A	INSULATION DETAIL FOR ADHERED SYSTEMS
PREVIOUS:	01/15/2024	PEEL STOP CLEAT
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF