



Note 1: Membrane must be fastened around the perimeter of the drain with the same fastening pattern as the field membrane, no less than one fastener per drain.

Note 2: Openings in the CDRs must face in opposite directions. Sealant must be behind the membrane at the CDRs' location.

Note 3: Duro-Last Drain Guard attachment tabs are secured to the roof membrane by heat welding. Do not mechanically fasten.

Note 4: Duro-Last Drain Boots are made to fit specific drain sizes. Never install a Duro-Last Drain Boot into a drain of a different size.

Note 5: All field welds shall be a minimum of 1-1/2 inches wide.

Note 6: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED:	N/A	DRAINAGE DETAIL FOR ADHERED FLEECE SYSTEMS
PREVIOUS:	06/22/2023	ROOF DRAIN WITH DRAIN GUARD
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF