



- Note 1: Lead flashings must be removed prior to installing Pipe Flashings.
- Note 2: Fasten the deck membrane with three approved plates and fasteners evenly spaced around the pipe.
- Note 3: All field welds must be a minimum of 1-1/2 in. (40 mm) wide.
- Note 4: Refer to specifications for vapor barrier, insulation, and cover board requirements.
- Note 5: Refer to chart for sizing specifications.

REVISED: N/A	TPO ROOF PENETRATION DETAIL FOR MECHANICALLY FASTENED SYSTEMS
PREVIOUS: 04/29/2026	UNIVERSAL PIPE FLASHING
SCALE: NONE	NEW CONSTRUCTION OR RE-ROOF