



- Note 1: Membrane must be fastened around the perimeter of the drain as per respective zone the drain is located within (field, perimeter, corner). No less than one fastener per drain.
- Note 2: The openings in the composite drain rings (CDR) must face in opposite directions. Sealant and CDRs are to match locations.
- Note 3: Insert the first CDR as low into the Drain Boot as possible, 6 inches minimum depth. The second CDR must be placed within 1/4 inch of the other.
- Note 4: All field welds shall be a minimum of 1-1/2 inches wide.
- Note 5: Refer to specifications for vapor barrier, insulation and cover board requirements.

REVISED:	N/A	DRAINAGE DETAIL FOR ADHERED FLEECE SYSTEMS
PREVIOUS:	01/06/2023	OVERFLOW DRAIN
SCALE:	NONE	NEW CONSTRUCTION OR RE-ROOF