

DURO-TECH TPO INSIDE AND OUTSIDE CORNERS

DESCRIPTION:

Duro-TECH TPO Inside and Outside Corners ("Corners") are used in corner areas encountered on Duro-TECH™ thermoplastic polyolefin ("TPO") membrane installations.

Corners are fabricated from reinforced TPO membrane.

ORDERING:

Corners are 6 x 6 inches (152 x 152 mm) and available in white, tan, and gray.

Custom sizes and colors available upon request.

AVAILABLE SIZES		
Size/Type – Color	Item #	Pkg Weight lb (kg)
6-in. (152 mm) Inside – White	13301TW	< 7 (3.18)
6-in. (152 mm) Outside – White	13302TW	< 7 (3.18)

STORAGE AND HANDLING:

- Keep away from ignition sources.
- Always store in a dry location protected from the elements.

PRECAUTIONS:

- Keep away from ignition sources.
- Wear proper personal protective equipment, such as gloves and eye protection, per the SDS.

INSTALLATION:

Installation must be completed in compliance with the appropriate Duro-TECH TPO details and specifications.

1. Prepare all affected surfaces to be welded with an approved TPO membrane cleaner, if necessary.
2. Heat (hot-air) weld the Corner to the TPO deck or parapet membrane with a minimum 1-1/2-inch (40-mm) weld.

Note: The use of Outside Corners is required.

Note: The use of Inside Corners is required at all inside wall transitions.

